

How to Install CUPS Driver (CPCL)

Mobile Label Printer

Rev. 1.00



1. Linux(SUSE, Fedora Core, RedHat)

1.1. Installation.

1. Extract this archive creating the sewoocpinstall_amd64 directory automatically.

```
# tar -zxvf sewoocpinstall_amd64.tar.gz
```

2. Open your favorite shell (bash, etc.) and
move to the sewoocpinstall_amd64 directory.

```
# cd sewoocpinstall_amd64
```

3. Execute the 'su' command to obtain super-user level permissions.

You must enter the root user's password for this to succeed. Be careful!.

4. Type 'make install' to install this package onto your computer.

```
# make install [Enter]
```

Or

```
> sudo sh setup.sh [Enter]
```

A successfull install should result in output similar to this:

```
# installing
cp ppd/*.gz install
cd install; exec ./setup
SEWOO TECH
SEWOO TECH CPCL CUPS driver installation Start
-----
```

Models included:

```
SEWOO LK-P11
SEWOO LK-P12
SEWOO LK-P30
SEWOO LK-P41
SEWOO LK-P43
```

Searching for ServerRoot, ServerBin, and DataDir tags in /etc/cups/cupsd.conf

ServerBin tag is present as an absolute path

DataDir tag is present as an absolute path

ServerRoot = /etc/cups
ServerBin = /usr/lib/cups
DataDir = /usr/share/cups

Copying rasterlbp11 filter to //usr/lib/cups/filter

Copying rasterlbp12 filter to //usr/lib/cups/filter

Copying rasterlbp30 filter to //usr/lib/cups/filter

Copying rasterlbp41 filter to //usr/lib/cups/filter

Copying rasterlbp43 filter to //usr/lib/cups/filter

Copying Model PPD files to //usr/share/cups/model/SEWOO

Restarting CUPS

Shutting down cupsd done

Starting cupsd done

Install Complete

Add printer queue using K Menu -> Utilities -> Printing -> Printing Manager, or

Add printer queue using OS tool, <http://localhost:631>, or <http://127.0.0.1:631>

5. Goto <http://127.0.0.1:631> or use your favorite CUPS admin tool.


Or K Menu -> Utilities -> Printing -> Printing Manager.

1.2. How to Add Printer (Example : SEWOO LK-P30)

1.2.1. How to Add Printer(SUSE, Fedora Core)


K Menu -> Utilities -> Printing -> Printing Manager.

Or <http://localhost:631>




Add → Add Printer/Class... → Next → Local Printer(Parallel, Serial, USB)


Or Network Printer(TCP)



→ Select Local port.



→ Manufacturer(SEWOO) and Model(LK-Pxx)



→ Input the printer driver name.

KDE Print

Add Printer Wizard

General Information

Enter the information concerning your printer or class. **Name** is mandatory, **Location** and **Description** are not (they may even not be used on some systems).


Name:

Location:

Description:

Help < Back Next > Cancel

→ End.



1.2.2. How to Add Printer(RedHat)

Start Application -> Preferences -> Printing Manager Or <http://localhost:631>

Add → Add Printer/Class... → Next

→ Local Printer(Parallel, Serial, USB)

Or Network Printer(TCP)

→ Manufacturer(SEWOOD) and Model(LK-Pxx)

→ End.

2. Linux(Ubuntu)

2.1. Installation.

1. Extract this archive creating the **sewoocplinstall_amd64** directory automatically.

```
# tar -zxvf sewoocplinstall_amd64.tar.gz
```

2. Open your favorite shell (bash, etc.) and

move to the **sewoocplinstall_amd64/install** directory.

```
# cd sewoocplinstall_amd64/install
```

3. Execute the 'su' command to obtain super-user level permissions.

You must enter the root user's password for this to succeed. Be careful!.

4. Type 'make install' to install this package onto your computer.

```
# ./setup.ubuntu Destination-Directory [Enter]
```

Destination Directory → Directory to copy ppd files

A successfull install should result in output similar to this:

```
# installing
cp ppd/*.gz install
cd install; exec ./setup
SEWOO TECH
SEWOO TECH CPCL CUPS driver installation Start
-----
```

Models included:

```
SEWOO LK-P11
SEWOO LK-P12
SEWOO LK-P30
SEWOO LK-P41
SEWOO LK-P43
```

Searching for ServerRoot, ServerBin, and DataDir tags in /etc/cups/cupsd.conf

ServerBin tag is present as an absolute path

DataDir tag is present as an absolute path

ServerRoot = /etc/cups

ServerBin = /usr/lib/cups

DataDir = Destination-Directory

Copying rasterlbp11 filter to //usr/lib/cups/filter

Copying rasterlbp12 filter to //usr/lib/cups/filter

Copying rasterlbp30 filter to //usr/lib/cups/filter

Copying rasterlbp41 filter to //usr/lib/cups/filter

Copying rasterlbp43 filter to //usr/lib/cups/filter

Copying Model PPD files to Destination-Directory

Restarting CUPS

Shutting down cupsd

done

Starting cupsd

done

Install Complete

Add printer queue using K Menu -> Utilities -> Printing -> Printing Manager, or

Add printer queue using OS tool, <http://localhost:631>, or <http://127.0.0.1:631>

5. Goto <http://127.0.0.1:631> or use your favorite CUPS admin tool.

Or K Menu -> Utilities -> Printing -> Printing Manager.

2.2. How to Add Printer

2.2.1. How to Add Printer(Ubuntu)

System -> Administration -> Printing. Or <http://localhost:631>

Menu(Printer) → Add Printer → Next

→ Local Printer(Parallel, Serial, USB)

Or Network Printer(TCP)

→ Manufacturer(SEWOO) and Model(LK-Pxx)

→ End.